



# Fraunhofer

## TESTED<sup>®</sup> DEVICE

RK Rose+Krieger GmbH  
RK DuoLine S60 Clean  
**Report No. RK 1404-704**

DUPLICATE

Statement of  
Qualification

Particle Emission

# Statement of Qualification

**Customer:** RK Rose+Krieger GmbH  
 Potsdamer Strasse 9  
 32375 Minden  
 Germany

**Component tested**

Category: Automation Components

Subcategory: Linear Units

Product name: RK DuoLine S60 Clean  
 (article number: TD16A5A1A13C01821; manufacturing date: CW 12/2014;  
 stroke: 1500 mm)

**Test result / Classification:**  
 (in acc. with ISO 14644-1)

When operated with an extraction system, the linear unit RK DuoLine S60 Clean (TD16A5A1A13C01821) is suitable for use in cleanrooms fulfilling the following air cleanliness specifications according to ISO 14644-1:

Parameter	Air Cleanliness Class
$v_1 = 0.1 \text{ m/s}; a = 4.0 \text{ m/s}^2$	ISO 1
$v_2 = 0.25 \text{ m/s}; a = 4.0 \text{ m/s}^2$	ISO 1
$v_3 = 0.5 \text{ m/s}; a = 4.0 \text{ m/s}^2$	ISO 1
<b>Overall result</b>	<b>ISO 1</b>

## Random sampling of particle emissions (airborne) at representative sites

Standards/Guidelines: VDI 2083-9.1; ISO 14644-1  
 The norms stated refer to the relevant editions applicable at the time of the tests.

Test devices: Optical particle counter:  
 LasAir II 110 with measuring ranges  $\geq 0.1 \mu\text{m}$ ,  $\geq 0.2 \mu\text{m}$ ,  $\geq 0.3 \mu\text{m}$ ,  $\geq 0.5 \mu\text{m}$ ,  
 $\geq 1.0 \mu\text{m}$  und  $\geq 5.0 \mu\text{m}$

Test environment parameters:

- Cleanroom Air Cleanliness Class (according to ISO 14644-1):..... ISO 1
- Airflow velocity:..... 0.45 m/s
- Airflow pattern:.....vertical laminar flow
- Temperature:.....  $22^\circ\text{C} \pm 0.5^\circ\text{C}$
- Relative humidity:.....  $45\% \pm 5\%$

Test procedure parameters:

- Extraction:..... 1420l/min
- Installation position:.....vertical, drive underneath
- Travelling distance:.....s = 1400 mm
- Velocities:..... $v_1 = 0.1 \text{ m/s}; v_2 = 0.25 \text{ m/s}; v_3 = 0.5 \text{ m/s}$
- Acceleration:..... $a = 4.0 \text{ m/s}^2$

The measuring devices used for the qualification tests are calibrated at regular intervals; their results can be traced back to national and international standards. In cases where no national standards exist, the test procedure implemented complies with the technical regulations and norms applicable at the time of the test. The relevant documentation can be viewed on request at any time.

For further information about the test environment and parameters, please refer to the Fraunhofer IPA test report.

Fraunhofer Institute for  
 Manufacturing Engineering and Automation IPA

Department of Ultraclean Technology  
 and Micromanufacturing

Nobelstrasse 12  
 70569 Stuttgart  
 Germany

Stuttgart, September 12, 2014

Place, date of first document issued

--

Place, current date

*Frank Bürger*  
 i. A. Frank Bürger, Project Manager Fraunhofer IPA

This document only applies to the named product in an unchanged state and is valid from the date of issue for a period of 5 years. The document can be verified under [www.tested-device.com](http://www.tested-device.com)